

---

Every ride

---

Dust removal

---

Shock wash (do not use power washer)

---

Visual check

---

Every 500h of use  
or 3 years

---

Hydraulic seals replacement. Please refer to HiRide  
service network: [www.hiride.bike/service/](http://www.hiride.bike/service/)

---

Every 1000h of use  
or 5 years

---

Slider components check

---

Bushings check